



NOTE: ECOLOGY MECHANICALLY FASTENED SYSTEMS REQUIRE ECOLOGY SCREWS AND PLATES 12" O.C. AROUND THE BASE OF THE BEAM.

PRESSURE TREATED WOOD BLOCKING MUST BE IMBEDDED IN LAYER OF ECOLOGY APPROVED SEALANT PRIOR TO FLASHING.

TITLE	
I BEAM FLASHING DETAIL	
NAME	
ERS-8F37	
APPROVED BY	DATE
APPLICABLE TO ECOLOGY	
ADHERED SYSTEMS	
ECOLOGY ROOF SYSTEMS	1400 HARBOR BLVD. SUITE #601 FULLERTON, CA 92835