



NOTE:
 1. Where the deck is supported by and fastened to the concrete wall, vertical wood nailers should be secured to the wall with suitable fasteners.

TITLE	SURFACE MOUNTED COUNTERFLUSH FOR CONCRETE PARAPET WALL	
NAME	ERS-MB-5	
APPROVED BY		DATE
APPLICABLE TO MODIFIED SYSTEMS		
ECOLOGY ROOF SYSTEMS		1400 HARBOR BLVD. SUITE #601 FULLERTON, CA 92835