



NOTE:

1. Follow SMACNA guidelines for size of opening and scupper design.
2. Flashing material shall extend at least 6" onto field.
3. Field base plies must be placed behind scupper.
4. All sheet metal joints on the scupper must be soldered and tested for watertightness.

| | |
|-------------------------------------|--------------------------------------------------------|
| TITLE | |
| SCUPPER PLACED THROUGH PARAPET WALL | |
| NAME | |
| ERS-MB23 | |
| APPROVED BY | DATE |
| APPLICABLE TO MODIFIED | |
| SYSTEMS | |
| ECOLOGY ROOF SYSTEMS | 1400 HARBOR BLVD. SUITE #601 FULLERTON, CA 92835 |