



NOTES:

1. This detail should be used only where the deck is supported by the wall.
2. The joints in the two pieces of flashing should not be soldered. Breaks in soldered joints could channel water behind the flashing. Clips at the bottom of the flashing are not necessary on flashings of 6" or less.

TITLE	
PARAPET WITH FLEXIBLE COUNTERFLASHING 2	
NAME	
ERS-MB30	
APPROVED BY	DATE
APPLICABLE TO MODIFIED	
SYSTEMS	
ECOLOGY ROOF SYSTEMS	1400 HARBOR BLVD. SUITE #601 FULLERTON, CA 92835