



NOTES:

1. An area divider is designed simply as a raised double wood member attached to a properly flashed wood base plate that is anchored to the roof deck. Area dividers should be located between the roof's expansion joints at 150–200 feet depending on the climatic conditions and area practices. They should never restrict the flow of water.

TITLE	MODIFIED AREA DIVIDER
NAME	ERS-MB11
APPROVED BY	DATE
APPLICABLE TO MODIFIED SYSTEMS	
ECOLGY ROOF SYSTEMS 1400 Harbor Blvd. Suite 601 Fullerton, CA 92835	